asecos

ID-Nr. 37276-047 Model IO90.195.120.K3.WDC



Dimensions	
Width (external)	1193.00 mm
Depth (external)	615.00 mm
Height (external)	2224.00 mm
Width (internal)	1050.00 mm
Depth (internal)	522.00 mm
Height (internal)	1647.00 mm
WE HELE A LET 1	Provide the second s

The available internal dimensions can vary depending on the interior equipment package.

Weight / Load	
Weight without interior equipment	424 kg
Distributed load	531.00 kg/m ²
Maximum load	600 kg
Ventilation	
Extraction air	75 DN
Frequency	50/60 Hz
Nominal voltage	230 V
Power consumption in operation	47,5 W
Outlet strips (Charging power)	
Fuse (1-phase)	16 A
Power max. (1-phase)	3,68 kW
Fuse (3-phase)	3 x 16 A
Power max. (3-phase)	11,04 kW
Colouring / Surface finish	
Body colour code	RAL 7016
Body colour	anthracite grey
Body surface finish	textured
Door / Drawer colour code	RAL 5010
Door / Drawer colour	gentian blue
Door / Drawer surface finish	textured
General Information	
Number of doors	2
Door opening angle	89.50°
Depth with open doors	1166 mm
Entry width transport base	1120 mm
Entry height transport base	90 mm
Customs tariff number	94032080



Safety storage cabinet ION-CLASSIC-90 Model IO90.195.120.K3.WDC, body colour anthracite grey (RAL 7016), with wing doors in gentian blue (RAL 5010)

Safe active storage of lithium-ion batteries with integrated 3-stage warning and fire supression system

Function / construction:

- Robust construction and longevity: triple hinged door, safety elements assembled outside the storage compartment for increased protection against corrosion, scratch- and impact-resistant surface, easy to clean
- Easy handling with comfort: smooth doors with permanent self-closing function and oil-dampened door closer; open doors with a minimum amout of force
- No unauthorised use: doors lockable with cylinder locking (integration in an existing locking system possible) and locking state indicator (red/green)
- Easy transport: integrated transport base with removable, optional base cover
- Easy alignment: adjusting aids to compensate for uneven floor
- **Ventilation:** integrated technical ventilation to avoid heat build-up, spinning wheel in the exhaust grid as an indicator of sufficient technical ventilation
- All-around protection: 90 minute fire protection from outside to inside (type 90 / type tested in accordance with EN 14470-1) and for more than 90 minutes fire resistance for fires from inside to outside
- **Safe storage and charging:** installed 3-stage warning and fire supression system including smoke detector, temperature sensor, visual and acoustic alarms and fire supression unit; triggers automatically in case of a fire; plug-in ready for connection to mains supply



